






How the **TIGHT-SEAL™** accessories work

Set up your barrier. Set up a ZipWall® barrier in desired configuration with the poles at least five feet apart. Allow four extra inches of plastic to overlap the head at the top of each pole.




Installing the Foam Rail. Each Foam Rail requires the use of one ZipWall® pole with the head and plate removed. Simply pull the head straight up and off.

Set up the Foam Rail. To install the clip on the Foam Rail, line up the pin under the clip with the hole on the Foam Rail. Put the clip on the Foam Rail with the pin in the hole and then press down hard. The clip will snap onto the Foam Rail. The clip is now permanently attached to the Rail.




Snap the Clip on the ball at the top of the ZipWall® pole. Now, with the Foam Rail attached to the pole, raise it into place, pressing the barrier against the ceiling.




Fits any length. With multiple Foam Rails you can seal any span. The Foam Rail easily overlaps each other allowing you to adjust to any barrier length.

Customize. If you need to create a custom length of Foam Rail, cut the aluminum and foam to the desired size using a hacksaw. Remove the plastic end from the discarded length of Foam Rail by pulling it straight out using pliers. Then press this plastic end into the newly cut Foam Rail.

Using the ZipWall® Side Clamp. First, set up a plastic barrier using the ZipWall® barrier system. At the wall end of the barrier place a pole so that the top plate touches the wall at the ceiling, and at the floor the pole is no more than two inches away from the wall. Use a GripDisk as needed. Also, allow an extra foot of material at each wall.



Attach the Side Clamp to the Foam Rail by pressing the thumb release. Place the Foam Rail into Side Clamp's rail catch and release thumb pressure. To center the Side Clamp on the rail, place at the Foam Rail label.



Put the Side Clamp and Foam Rail into place.

Open the Side Clamp by squeezing the handles together, as shown. While clamp is open, place the Foam Rail between the plastic barrier and the pole moving the clamp so that the curved rubber end is between the pole and wall. Release the pressure allowing the rubber end to grasp the pole. This will then push the Foam Rail against the plastic barrier material and the wall.

